

## TEL Furnace Parts List

No.	MAKER	Picture	Part No.	Description	Q'TY	Condition	Remark
1	TEL			OMRON S8VS-01505	1	Used	
2	TEL		2184-020931-12	TTLM02-11, MDIF5B	1	Used	
3	TEL		2184-020940-12	TTLM01-11, MDIF2B	1	Used	
4	TEL		1181-000826-14	DI016-3	1	Used	
5	TEL		2181-020069-17	HSDL-VLV-1/F , (2108-020069-11)	1	Used	200mm
6	TEL		3880-200121-12	TTLA07-13, F-MFC_16, (3895-120916-12)	5	Used	
7	TEL		2180-020559-13	TTL-T0066 LPIF PCA	1	Used	
8	TEL		2184-020929-11	PCA, RESET SW BOARD, TTL0033 / 2181-020144-11	2	Used	
9	TEL		3880-200058-11	TTLE29-11 CONNECT-D1 3895-120537-11	4	Used	
10	TEL		SBX93-100031-11	SBX08-000019-11, IOP8	12	Used	
11	TEL		3880-200134-11	MMI CONV2 PCB, I/F TTLE37-11	1	Used	
12	TEL		3880-200133-11	MMI INTFC2 PCB	2	Used	
13	TEL			VEXTA DFC5107P DRIVER	3	Used	
14	TEL		EC80-000180-15	TEB211-15 GRSO	3	Used	INDY PLUS 300MM
15	TEL		EC80-000180-12	TEB211-12 GRSO	2	Used	INDY PLUS 300MM



## TEL Furnace Parts List

No.	MAKER	Picture	Part No.	Description	Q'TY	Condition	Remark
16	TEL		2180-021107-11	TTLM01-12, MDIF2B	1	Used	INDY PLUS 300MM
17	TEL		2180-021108-12	TTLM02-12, MDIF5B	1	Used	INDY PLUS 300MM
18	TEL		2184-020943-11	TTLD03-11 DSPP128B B/D, (1181-000853-12)	2	Used	
19	TEL		2184-020942-12	TTLD02-11, DSP224B	1	Used	
20	TEL		3880-200048-12	GHOST-SQUARE-RS02, SH-2 PC0520-0	2	Used	INDY PLUS 300MM
21	TEL		3880-200055-12	GHOST-SQUARE-RS03, SH-2 PC0543-1	3	Used	
22	TEL			GHOST-SQUARE-RS07, SH-2 PC0500-1	1	Used	
23	TEL		5880-000036-12	PCB GHOST-SQUARE-RS09 5895-100398-12	1	Used	
24	TEL		5880-000015-12	TTLC19-11 GHOST-SQUARERS-08 5895-100018-12	4	Used	
25	TEL		2180-021298-11	HEATER POWER CONTROLLER -POWER CPU(TTLC04-11) -POWER CONTROL(TTLA10-11)	1	Used	INDY PLUS 300MM
26	TEL		3880-200122-12 3880-200122-13	TTLA08-13, F-MFC, AI, 4 PCB (3895-120917-12 / 3895-120917-13)	3 1	Used	INDY PLUS 300MM
27	TEL		2180-020891-13	TTLI27-11 DIO INTLK PCB (2195-125029-13)	2	Used	INDY PLUS 300MM
28	TEL		3880-200057-12	TTLE28-11, CONNECT-MFC 3895-120536-12	1	Used	
29	TEL		5180-000005-12	PCB, IF TTLE48-11 PWR STATUS PCB	2	Used	
30	TEL		3881-020002-11	3884-200093-11	1	Used	

## TEL Furnace Parts List

No.	MAKER	Picture	Part No.	Description	Q'TY	Condition	Remark
31	TEL		3881-020001-12	TTLE03-11, M780_CPU B/D / 3884-200092-11	1	Used	
32	TEL		2180-021123-13 2180-021125-12 2180-021124-13 COSEL P/S	TTLC06-11 TEMP CTRL_CPU B/D TTLE50-11 M560 AS1100 B/D TTLA15-11 TEMP CTRL_A/D B/D COSEL_PMC15E-1	1 1 1 1	Used	M560A PARTS
33	TEL		2180-020932-11	TTLD19-11 DIO IF B/D 2195-125192-11	8	Used	
34	TEL		3880-200061-11	MODEL-780 TEMP CONTROLLER	2	Used	VER. 2.10
35	TEL		3880-200061-19	MODEL-780 TEMP CONTROLLER	1	Used	VER. 3.00
36	TEL		3880-200206-17	MODEL-781 TEMP CONTROLLER	1	Used	VER. 3.01
37	TEL		2180-021232-12	CONTROL BOX	2	Used	
38	TEL		E239-010003-11	UP017/001A	1	Used	
39	TEL		2180-020557-12	RMT-DIO16-3	5	Used	INDY PLUS 300MM
40	TEL		6180-000003-12	ECAT DIO #3	1	Used	
41	TEL		6110-400224-X1	ECAT AIO TTLA23-11 / 5195-101401-	3	Used	
42	TEL		5880-000029-11	PCB I/O TTLD30-11 MODULE2 PCB 5895-100310-11	2	Used	
43	TEL		5880-00030-12	SW300B/MIO-SB	2	Used	
44	TEL		3880-200064-11	TTLE31-11 / FILTER-17 ASY 3895-120599-11	2	Used	
45	TEL		5880-000101-11	TTLE69-11 / LSIF IO 5895-100526-11	2	Used	

## TEL Furnace Parts List

No.	MAKER	Picture	Part No.	Description	Q'TY	Condition	Remark
46	TEL		5880-000130-16	TTL C24 LSIF PCB CPU_V2.07 / FPGA_V0100 5895-100641-16	2	Used	
47	TEL		GU-172-2A	DR BOARD	1	Used	
48	TEL		GU-172-1A	PT BOARD	1	Used	
49	TEL		GU-138-2A	I/O BOARD	1	Used	
50	TEL		UC10-525Y1	COM-PL-02-D	1	Used	
51	TEL		MDIF01A	MDIF01A	3	Used	
52	TEL		1187-058062-12	MCE-31041C / DI MODULE	1	Used	
53	TEL		MC31045B	MC31045B	1	Used	
54	TEL		1181-00024716	MC31048	1	Used	
55	TEL		MC-31107A	MC-31107A	1	Used	
56	TEL		118100025518	MC31042A	1	Used	
57	TEL		TBX-36	TBX-36	1	Used	
58	TEL		MC-31108A	MC-31108A	3	Used	
59	VEXTA		A5805-9015KTGE	MOTOR	2	Used	
60	VEXTA		A4276-9115E	MOTOR	1	Used	

### TEL Furnace Parts List

No.	MAKER	Picture	Part No.	Description	Q'TY	Condition	Remark
61	VEXTA		UDX5107-A5	5 PHASE DRIVER	5	Used	